









$\mu$  PD78F0372,78F0373,78F0382,78F0383  
IOL vs VOL - VDD(P27)  
(Ta = -40°C)




$\mu$  PD78F0372,78F0373,78F0382,78F0383  
IOL vs VOL - VDD(P124)  
(Ta = -40°C)












$\mu$  PD78F0372,78F0373,78F0382,78F0383  
IOL vs VOL - VDD(P24)  
(Ta = 25°C)




$\mu$  PD78F0372,78F0373,78F0382,78F0383  
IOL vs VOL - VDD(P124)  
(Ta = 25°C)





$\mu$  PD78F0372,78F0373,78F0382,78F0383  
IOL vs VOL - VDD(P27)  
(Ta = 85°C)



$\mu$  PD78F0372,78F0373,78F0382,78F0383  
IOL vs VOL - VDD(P124)  
(Ta = 85°C)

