

TSOP (2)
Mount Pad Dimensions





$$I_2 = L + \beta_1 + \beta_2$$

$$b \le b_2 \le e - \gamma$$

l<sub>2</sub> and b<sub>2</sub> can get by following formula and value e and b from package drawing figure and below parameter table.

## • Dimension parameter

(Unit: mm)

е	1.27	1.00	0.80	0.65	0.40
α	0.05 to 0.10	←	←	<b>←</b>	<b>←</b>
$\beta_1$	0.20 to 0.25	←	←	←	←
$\beta_2$	0.20 to 0.40	←	<b>←</b>	<b>←</b>	<b>←</b>
γ	0.30	←	←	<b>←</b>	0.20

(Reference values based on the former EIAJ ED-7402 standard)