## Old Company Name in Catalogs and Other Documents

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1<sup>st</sup>, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.



#### Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights
  of third parties by or arising from the use of Renesas Electronics products or technical information described in this document.
  No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights
  of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.

- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



## **User's Manual**

# $\mu$ SAP77016-B17

## **AAC Audio Encoder Middleware**

## **Target Device**

 $\mu$ PD77110

 $\mu$ PD77113A

 $\mu$ PD77114

 $\mu$ PD77115

 $\mu$ PD77210

 $\mu$ PD77213

Document No. U16314EJ1V0UM00 (1st edition) Date Published January 2003 NS CP(N)

© NEC Electronics Corporation 2003

Printed in Japan

## [MEMO]

Windows is either a registered trademark or a trademark of Microsoft Corporation in the United States and/or other countries.

- The information in this document is current as of January, 2003. The information is subject to change without notice. For actual design-in, refer to the latest publications of NEC Electronics data sheets or data books, etc., for the most up-to-date specifications of NEC Electronics products. Not all products and/or types are available in every country. Please check with an NEC Electronics sales representative for availability and additional information.
- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this document or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative
  purposes in semiconductor product operation and application examples. The incorporation of these
  circuits, software and information in the design of a customer's equipment shall be done under the full
  responsibility of the customer. NEC Electronics assumes no responsibility for any losses incurred by
  customers or third parties arising from the use of these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that the possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, fire-containment and anti-failure features.
- NEC Electronics products are classified into the following three quality grades: "Standard", "Special" and "Specific".
  - The "Specific" quality grade applies only to NEC Electronics products developed based on a customer-designated "quality assurance program" for a specific application. The recommended applications of an NEC Electronics product depend on its quality grade, as indicated below. Customers must check the quality grade of each NEC Electronics product before using it in a particular application.
  - "Standard": Computers, office equipment, communications equipment, test and measurement equipment, audio and visual equipment, home electronic appliances, machine tools, personal electronic equipment and industrial robots.
  - "Special": Transportation equipment (automobiles, trains, ships, etc.), traffic control systems, anti-disaster systems, anti-crime systems, safety equipment and medical equipment (not specifically designed for life support).
  - "Specific": Aircraft, aerospace equipment, submersible repeaters, nuclear reactor control systems, life support systems and medical equipment for life support, etc.

The quality grade of NEC Electronics products is "Standard" unless otherwise expressly specified in NEC Electronics data sheets or data books, etc. If customers wish to use NEC Electronics products in applications not intended by NEC Electronics, they must contact an NEC Electronics sales representative in advance to determine NEC Electronics' willingness to support a given application.

#### (Note

- (1) "NEC Electronics" as used in this statement means NEC Electronics Corporation and also includes its majority-owned subsidiaries.
- (2) "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above).

M8E 02.11-1

## **Regional Information**

Some information contained in this document may vary from country to country. Before using any NEC Electronics product in your application, please contact the NEC Electronics office in your country to obtain a list of authorized representatives and distributors. They will verify:

- Device availability
- · Ordering information
- Product release schedule
- Availability of related technical literature
- · Development environment specifications (for example, specifications for third-party tools and components, host computers, power plugs, AC supply voltages, and so forth)
- Network requirements

In addition, trademarks, registered trademarks, export restrictions, and other legal issues may also vary from country to country.

#### NEC Electronics America, Inc. (U.S.) • Filiale Italiana

Santa Clara, California Tel: 408-588-6000 800-366-9782 Fax: 408-588-6130 800-729-9288

## **NEC Electronics (Europe) GmbH**

Duesseldorf, Germany Tel: 0211-65 03 01 Fax: 0211-65 03 327

#### • Sucursal en España

Madrid, Spain Tel: 091-504 27 87 Fax: 091-504 28 60

#### • Succursale Française

Vélizy-Villacoublay, France Tel: 01-30-67 58 00 Fax: 01-30-67 58 99

Milano, Italy Tel: 02-66 75 41 Fax: 02-66 75 42 99

#### Branch The Netherlands

Eindhoven, The Netherlands Tel: 040-244 58 45 Fax: 040-244 45 80

#### Tyskland Filial

Taeby, Sweden Tel: 08-63 80 820 Fax: 08-63 80 388

## United Kingdom Branch

Milton Keynes, UK Tel: 01908-691-133 Fax: 01908-670-290

#### **NEC Electronics Hong Kong Ltd.**

Hong Kong Tel: 2886-9318 Fax: 2886-9022/9044

#### **NEC Electronics Hong Kong Ltd.**

Seoul Branch Seoul, Korea Tel: 02-528-0303 Fax: 02-528-4411

#### **NEC Electronics Shanghai, Ltd.**

Shanghai, P.R. China Tel: 021-6841-1138 Fax: 021-6841-1137

#### **NEC Electronics Taiwan Ltd.**

Taipei, Taiwan Tel: 02-2719-2377 Fax: 02-2719-5951

#### **NEC Electronics Singapore Pte. Ltd.**

Novena Square, Singapore

Tel: 6253-8311 Fax: 6250-3583

#### **PREFACE**

Target Readers This manual is for users who design and develop  $\mu$ PD77016 Family application systems.

 $\mu$ PD77016 Family is the generic name for the  $\mu$ PD7701x family ( $\mu$ PD77015, 77016, 77017, 77018, 77018A, 77019), the  $\mu$ PD77111 Family ( $\mu$ PD77110, 77111, 77112, 77113A, 77114, 77115) and the  $\mu$ PD77210 Family ( $\mu$ PD77210, 77213). However, this

manual is for  $\mu$  PD77110, 77113A, 77114, 77115, 77210, and 77213 devices.

Purpose The purpose of this manual is to help users understand the supporting middleware when

designing and developing  $\mu$ PD77016 Family application systems.

Organization This manual consists of the following contents.

OVERVIEW

- LIBRARY SPECIFICATIONS
- INSTALLATION
- SYSTEM EXAMPLES
- SAMPLE PROGRAM SOURCE

How to Read This Manual

It is assumed that the reader of this manual has general knowledge in the fields of electrical engineering, logic circuits, microcontrollers, and the C language.

To learn about  $\mu$ PD77111 Family hardware functions

 $\rightarrow$  Refer to  $\mu$  PD77111 Family User's Manual Architecture.

To learn about  $\mu$  PD77210 Family hardware functions

 $\rightarrow$  Refer to  $\mu$  PD77210 Family User's Manual Architecture.

To learn about  $\mu$ PD77016 Family hardware functions

 $\rightarrow$  Refer to  $\mu$  PD77016 Family User's Manual Instruction.

Conventions Data significance: Higher digits on the left and lower digits on the right

Active low representation: XXX (overscore over pin or signal name)

Note: Footnote for item marked with Note in the text

Caution: Information requiring particular attention

Remark: Supplementary information
Numerical representation: Binary ... XXXX or 0bXXXX

Decimal ... XXXX

Hexadecimal ... 0xXXXX

## **Related Documents**

The related documents listed below may include preliminary versions. However, preliminary versions are not marked as such.

#### **Documents Related to Devices**

Part Number	Pamphlet	Data Sheet	User's Manual		Application Note
			Architecture	Instructions	Basic Software
μPD77110	U12395E	U12801E	U14623E	U13116E	U11958E
μPD77111					
μPD77112					
μPD77113A		U14373E			
μPD77114					
μPD77115		U14867E			
μPD77210		U15203E	U15807E		
$\mu$ PD77213					

## **Documents Related to Development Tools**

Do	Document No.		
RX77016 User's Manual	Function	U14397E	
	Configuration Tool	U14404E	
RX77016 Application Note	HOST API	U14371E	

#### **Documents Related to Middleware**

Document Name	Document No.
μSAP77106-B08 User's Manual (AAC Decoder)	U15152E
μSAP77106-B17 User's Manual (AAC Encoder)	This manual

#### **Documents Related to Standard**

Document Name	Date Published
ISO/IEC 13818-7 MPEG-2 Advanced Audio Coding, AAC	April, 1997

Caution The related documents listed above are subject to change without notice. Be sure to use the latest version of each document for designing.

## **CONTENTS**

CHAP	TER 1	OVERVIEW	9
1.1	Middle	ware	9
1.2	AAC A	udio Encoder	9
	1.2.1	Encoder outline	10
1.3	Compr	essed Data Format	12
	1.3.1	ADIF format outline	12
	1.3.2	ADTS format outline	12
1.4	Produc	ct Overview	13
	1.4.1	Features	13
	1.4.2	Function	13
	1.4.3	Operating environment	13
	1.4.4	Performance	15
	1.4.5	Directory configuration	16
CHAP	TER 2	LIBRARY SPECIFICATIONS	17
2.1	Library	/ Overview	17
2.2	Applic	ation Processing Flow	18
2.3	Functi	on Specifications	19
	2.3.1	AACENC_Start function	19
	2.3.2	AACENC_Encode function	20
	2.3.3	AACENC_GetVersion function	21
2.4	Param	eters Necessary for Compression	22
2.5	Memoi	y Structure	24
	2.5.1	Scratch area	24
	2.5.2	Static area	24
	2.5.3	I/O buffers	25
CHAP	TER 3	INSTALLATION	26
3.1	Installa	ation Procedure	26
3.2	Sample	e Program Creation Procedure	27
3.3	Symbo	l Naming Conventions	28
CHAP	TER 4	SYSTEM EXAMPLE	29
4.1	Simula	tion Environment Using Timing File	29
4.2	Operat	ion	29
APPEI	NDIX S	SAMPLE PROGRAM SOURCE	30
<b>A.</b> 1	l Heade	r File (aacenc.h)	30
A.2	2 Includ	e File for Sample Program (sample.inc)	31
<b>A.</b> 3	3 Sampl	e Source File (sample.asm)	33
<b>A.</b> 4	Timing	File for Parameter Information (value.tmg)	38
A.5	Timing	g File for Data Input (pcm_in.tmg)	39
A.6	Timing	g File for Data Output (stream_out.tmg)	41

## LIST OF FIGURES

Figure No.	Title	Page
1-1. Encoder Configuration Example		10
1-2. System Configuration Example		10
1-3. Timing Diagram		11
1-4. ADIF Format		12
1-5. ADTS Format		12
2-1. Application Processing Flow		18
2-2. Structure Consisting of Parameters Neces	sary for Compression	22
2-3. User-Defined Input Buffer (PCM Buffer)		25
2-4. User-Defined Output Buffer (Bit Stream Bu	uffer)	25
	LIST OF TABLES	
Table No.	Title	Page
1-1. Sampling Frequencies		9
1-2. Maximum Bit Rates		
1-3. Required Memory Sizes		
1-4. Software Tools		
1-5. MIPS Values of 1-Frame Compression Pro		
2-1. List of Library Functions		17
2-2. Sampling Frequencies		
2-3. Symbol Name/Memory Sizes		
3-1. Symbol Naming Conventions		28
o i. Cymbol Naming Conventions		20

#### **CHAPTER 1 OVERVIEW**

#### 1.1 Middleware

Middleware is the name given to a group of software that has been tuned so that it draws out the maximum performance of the processor and enables processing that is conventionally performed by hardware to be performed by software.

The concept of middleware was introduced with the development of a new high-speed processor, the DSP, in order to facilitate operation of the environments integrated in the system.

By providing appropriate speech codec and image data compression/decompression-type middleware, NEC Electronics is offering users the kind of technology essential in the realization of a multimedia system for the  $\mu$ PD77016 Family, and is continuing its promotion of system development.

 $\mu$ SAP77016-B17 is middleware that provides AAC-technology encoding functions.

#### 1.2 AAC Audio Encoder

AAC stands for Advanced Audio Coding.

MPEG-2 AAC is an audio coding method that achieves a high quality and a high compression rate by removing compatibility with MPEG-1 audio. The  $\mu$ SAP77016-B17 conforms to this coding method.

The compressed data format conforms to "ISO/IEC 13818-7 MPEG-2 Advanced Audio Coding, AAC". The audio data that is handled is 16-bit linear PCM data sampled at a frequency of 8 kHz to 96 kHz (refer to Table 1-1).

**Table 1-1. Sampling Frequencies** 

Frequency [Hz]
8000
11025
12000
16000
22050
24000
32000
44100
48000
64000
88200
96000

#### 1.2.1 Encoder outline

Figure 1-1 shows an example of the configuration of an encoder using the  $\mu$ SAP77016-B17. Figure 1-2 shows an example of the configuration of a system that includes an encoder using the  $\mu$ SAP77016-B17.

Figure 1-1. Encoder Configuration Example

Variable bit Sampling frequency 8 kHz to 96 kHz rate 16-bit Encoder (AAC) ➤ OUT ADC (Analog audio data) (16-bit linear (Compression data)

PCM data)

CD player Evaluation board AUDIO SERIAL INTERFACE LINE IN DSP PARALLEL PORT PC

Figure 1-2. System Configuration Example

#### (1) Input data

The input data is 16-bit linear PCM data sampled at 8 kHz to 96 kHz (refer to Table 1-1).

#### (2) AAC audio encoder

The AAC audio encoder reads 16-bit linear PCM data and outputs data while controlling the code quantity at a set bit rate. The bit rate per frame is variable.

The maximum value of the bit rate that can be set differs depending on the sampling frequency. The bit rate takes any value up to the maximum value. Table 1-2 shows the maximum value of the bit rate at a given sampling frequency.

**Table 1-2. Maximum Bit Rates** 

Sampling frequency [Hz]	Maximum bit rate [bps/ch]
8000	48000
11025	66150
12000	72000
16000	96000
22050	132300
24000	144000
32000	192000
44100	264600
48000	288000
64000	384000
88200	529200
96000	576000

## (3) Timing diagram

Figure 1-3 shows the timing diagram of the AAC audio encoder.




Figure 1-3. Timing Diagram

- <1> 16-bit linear PCM data of one frame is input.
- <2> The 16-bit linear PCM data of one frame is buffered and compressed.
- <3> The compressed data is buffered and output.
- <4> The user performs appropriate processing.

#### 1.3 Compressed Data Format


For details of the compressed data format, refer to standards (ISO/IEC 13818-7 MPEG-2 Advanced Audio Coding, AAC).

The  $\mu$ SAP77016-B17 specifications conform to standards.

#### 1.3.1 ADIF format outline

Figure 1-4 shows the structure of ADIF format.

Figure 1-4. ADIF Format



Remark Header: Contains information for synchronizing, such as sampling frequency, bit rate, and mode.

Audio data: This is information related to the audio sample. It consists of multiple RAW data bit streams.


RAW data: This is a bit stream of the smallest unit that is decoded.

\*1: Bit alignment

#### 1.3.2 ADTS format outline

Figure 1-5 shows the structure of ADTS format.

Figure 1-5. ADTS Format



Remark Frame header: Contains information for synchronizing, such as sampling frequency, bit rate, and mode.

Variable header: This is information needed in decoding, such as the number of RAW data bit streams included in the audio data.

Audio data: This is information related to the audio sample. It consists of multiple RAW data bit streams. RAW data: This is a bit stream of the smallest unit that is decoded. There are up to four in one frame.

\*1: Error check

\*2: Bit alignment

#### 1.4 Product Overview

#### 1.4.1 Features

- Supports MPEG-2 AAC (Advanced Audio Coding) LC (Low Complexity) profile.
- Supports only two front channels (mono/stereo).
- 16-bit linear PCM data input.
- Code quantity control at set bit rate (refer to Table 1-2 Maximum Bit Rates) (bit rate per frame variable).
- Sampling frequency: 8 kHz to 96 kHz (refer to Table 1-1 Sampling Frequencies).
- Codes 1024 samples/frame in mono mode (1 channel).
- Codes 2048 samples/frame in stereo mode (2 channels).
- ADTS, ADIF, and RAW formats used as compressed data formats.
- Short block processing, TNS processing, and intensity stereo processing not supported.

#### 1.4.2 Function

The  $\mu$ SAP77016-B17 converts 16-bit linear PCM data of one frame into compressed data.

#### 1.4.3 Operating environment

## (1) Operable DSPs:

 $\mu$ PD77110, 77113A, 77114, 77115, 77210, 77213

#### (2) Required memory size:

 $\mu$ SAP77016-B17 requires memory sizes shown in the following table.

**Table 1-3. Required Memory Sizes** 

Memory		Туре	Size [Kwords]
Instruction memory		-	4.8
X memory	RAM	Scratch area	4.7
		Static area	2.0
	ROM		3.4
Y memory	RAM	Scratch area	4.0
		Static area	0.1
		Library area	0.1
	ROM		2.8

## Caution Place the X memory and Y memory areas used for the library in the internal ROM/RAM space.

The required memory size shown above does not include the audio data and bit stream data buffers. Refer to 2.5.3 I/O buffers.

#### **Remark** One word of instruction memory is 32 bits.

One word of X memory or Y memory is 16 bits.

## (3) Required A/D converter specifications

2 channels, 16-bit resolution, sampling frequency shown in Table 1-1

## (4) Software tools (Windows® version)

**Table 1-4. Software Tools** 

Relevant DSP	Software Tools
$\mu$ PD77110 Family	WB77016 (Workbench (Assembler/Linker)) HSM77016 (High-speed simulator) ID77016 (Debugger)
μPD77210 Family	Atair Developer Studio (Workbench (Assembler/Linker)) $ \mu  \text{PD7721x High-speed simulator} \\ \mu  \text{PD7721x Debugger} $

Remark These DSP software tools are produced by Atair Software GmbH.

## 1.4.4 Performance

Table 1-5 shows the MIPS values (measured values) necessary for real-time execution of processing of one frame.

• Measurement conditions

Simulator: HSM77016 (µPD77016 high-speed simulator)

Sampling frequency: 32 kHz, 44.1 kHz, 48 kHz

Evaluation result: The processing speed is measured when a stereo/mono audio file is compressed, and the average value and maximum value are calculated.

The processing speed of only the AACENC\_Encode function is included in compression. The processing speed of the other functions and interrupt handlers is not included.


Table 1-5. MIPS Values of 1-Frame Compression Processing (Measured Values)

Sampling frequency [kHz]		32		44.1			48			
Setting bit rate [kbps]		64	96	128	64	96	128	64	96	128
Average value	Stereo	24.9	27.9	28.4	30.7	33.5	37.5	33.5	36.7	41.2
[MIPS]	Mono	13.4	13.7	14.8	17.9	18.2	18.8	19.1	19.7	20.7
Maximum value	Stereo	42.2	49.8	51.2	50.3	58.5	67.7	54.6	63.8	73.8
[MIPS]	Mono	24.9	26.9	28.5	33.1	34.6	36.4	35.3	36.5	39.5

**Remark** These MIPS values were measured when evaluation was made by NEC Electronics. The maximum values do not guarantee the worst values.

## 1.4.5 Directory configuration

The directory configuration of the  $\mu$ PSAP77016-B17 is shown below.



A summary of each directory is shown below.

• library

This directory contains library files.

• smp/aacenc

This directory contains sample program source files, header files and timing files.

## **CHAPTER 2 LIBRARY SPECIFICATIONS**

## 2.1 Library Overview

 $\mu\,\text{SAP77016-B17}$  provides the following three functions.

**Table 2-1. List of Library Functions** 

Function Name	Function
AACENC_Start	Initialization
AACENC_Encode	Compression process
AACENC_GetVersion	Obtain version information

## 2.2 Application Processing Flow

Figure 2-1 shows an example of the processing of an application that uses  $\mu$ SAP77016-B17.




Figure 2-1. Application Processing Flow

**Remark** The 16-bit linear PCM data input processing of the interrupt handler is dependent upon the hardware of the target system. Therefore, the user should design the input processing in accordance with their target system.

#### 2.3 Function Specifications

## 2.3.1 AACENC\_Start function

The AACENC\_Start function initializes each parameter used by the encoder. It outputs the first header in the ADIF format to the bit stream buffer only in the ADIF format. Call this function only once before using the AACENC\_Encode function.

[Classification] AAC encoder initialization processing

[Function name] AACENC\_Start

[Summary of function] Initializes the parameters used by the  $\mu$ SAP77016-B17 (bit rate, number of audio channels,

sampling frequency, compression format, compression method, and buffer pointer used by

 $\mu$ SAP77016-B17).

If the compression format is ADIF only, this function outputs the first header in the ADIF

format to the bit stream buffer.

[Format] call AACENC\_Start

[Arguments] R0L First address of structure consisting of parameters necessary for compressing in X

memoryNote 1

R1L First address of output buffer (bit stream buffer) for encoder in X memory<sup>Note 2</sup>.

The ADIF header is output to this bit stream buffer only when encoding is performed

in the ADIF format.

R2L First address of static area in X memory Note 2

R3L First address of scratch area in X memoryNote 2

R4L First address of static area in Y memory<sup>Note 2</sup>

R5L First address of scratch area in Y memory Note 2

[Return value] R0L When 0 or greater: Size of compressed bit stream (number of bytes)

When negative: Error

An error is returned if any of the following conditions is satisfied.

• If a value other than 0 or 1 is set to the speaker\_config member of the structure

consisting of the parameters necessary for compression Note 1.

• If a sampling frequency other than those supported by the  $\mu$ SAP77016-B17 is set to the higher word and lower word of the sampling\_freq member of the structure

consisting of the parameters necessary for compression Note 1.

[Registers used] r0, r1, r2, r3, r5, dp0, dp4

[Hardware resources] Maximum stack level 2

Maximum loop stack level 1
Maximum number of repeats 7

Maximum number of cycles 13937

Notes 1. For the parameters necessary for compression, refer to 2.4 Parameters Necessary for Compression.

2. For the memory area and I/O buffer, refer to 2.5 Memory Structure.

Caution Secure a memory area before calling this function.

#### 2.3.2 AACENC\_Encode function

The AACENC\_Encode function compresses audio data of 16 bits  $\times$  2048 samples (stereo) or 16 bits  $\times$  1024 samples (mono) at a specified bit rate.

[Classification] AAC encode processing [Function name] AACENC\_Encode

[Summary of function] Compresses the 16-bit linear PCM data in the PCM buffer and then outputs the compressed

data to the bit stream buffer.

[Format] call AACENC\_Encode

[Arguments] R0L First address of structure consisting of parameters necessary for compressing in X

memoryNote 1

R1L First address of input buffer (PCM buffer) for data input for encoder in X memory<sup>Note 2</sup>
R2L First address of output buffer (bit stream buffer) for data output from encoder in X

memoryNote 2

R3L First address of static area in X memory<sup>Note 2</sup>
R4L First address of static area in Y memory<sup>Note 2</sup>

[Return value] R0L When 0 or greater: Size of compressed bit stream (number of bytes)

When negative: Error

If the AACENC\_Encode function is called after the AACENC\_Start function has

returned an error, the AACENC\_Encode function also returns an error.

[Registers used] r0, r1, r2, r3, r4, r5,

dp0, dp1, dp2, dp3, dp4, dp5, dp6, dp7, dn0, dn1, dn2, dn3, dn4, dn5, dn6, dn7,

dmx, dmy

[Hardware resources] Maximum stack level 6

Maximum loop stack level 3
Maximum number of repeats 51

Maximum MIPS value 73.8 MIPS (48 kHz sampling, 128 Kbps, stereo)

Notes 1. For the parameters necessary for compression, refer to 2.4 Parameters Necessary for Compression.

2. For the memory area and I/O buffer, refer to 2.5 Memory Structure.

Caution On completion of encoding, the user should input muted data of 1 frame (2048 words (stereo)/1024 words (mono)) to the PCM buffer and call the AACENC\_Encode function three times. This can prevent information of the previous audio data from affecting compression of the next audio data.

## 2.3.3 AACENC\_GetVersion function

The AACENC\_GetVersion function returns the version number of the  $\mu$ SAP77016-B17.

[Classification] Version information acquisition

[Function name] AACENC\_GetVersion

[Function] Returns the version number of the  $\mu$ SAP77016-B17 library in a 32-bit value.

Version when R0 = 0x00'0x0001'0x0100: V1.01

[Format] AACENC\_GetVersion

[Arguments] None

[Return value] R0H Major version number

R0L Minor version number

[Registers used] r0

[Hardware resources] Maximum stack level 0

Maximum loop stack level 0
Maximum number of repeats 0
Maximum number of cycles 6

## 2.4 Parameters Necessary for Compression

Secure a structure (refer to Figure 2-2) consisting of the parameters necessary for compression on X memory. Set the information on each parameter to this structure before calling the AACENC\_Start and AACENC\_Encoder functions.




Figure 2-2. Structure Consisting of Parameters Necessary for Compression

<1> bitrate (2 words): This parameter sets the bit rate (bps).

Example: To set the bit rate to 264600 bps (0t264600 = 0x40998), set the higher word to 0x0004 and the lower word to 0x0998.

- <2> speaker\_config (1 word): This parameter sets the number of audio channels. If a value other than 0 or 1 is set to this parameter, the AACENC\_Start function returns an error.
  - 0: Mono (1 ch)
  - 1: Stereo (2 chs)

**Example** To select stereo (2 chs), set speaker\_config to 0x0001.

<3> sampling\_freq (2 words): This parameter specifies the sampling frequency (Hz). The frequencies that can be specified are listed in Table 2-2 below.

If a frequency not listed in this table is specified, the AACENC\_Start function returns an error.

Table 2-2. Sampling Frequencies

Frequency [Hz]			
8000			
11025			
12000			
16000			
22050			
24000			
32000			
44100			
48000			
64000			
88200			
96000			

**Example** To set the bit rate to 96000 Hz (0t96000 = 0x17700), set the higher word of sampling\_freq to 0x0001, and the lower word to 0x7700.

- <4> header\_type (1 word): This parameter specifies the header type. The following header types can be specified.
  - 0: RAW format (without header)
  - 1: ADIF format
  - 2: ADTS format

**Example** To select the ADTS format, set header\_type to 0x0002.

- <5> mpeg\_id (1 word): This parameter specifies the compression method. The  $\mu$ SAP77016-B17 does not support MPEG-4/AAC. Therefore, be sure to set mpeg\_id to 0x0001 .
  - 0: Setting prohibited (MPEG-4/AAC)
  - 1: MPEG-2/AAC

#### 2.5 Memory Structure

With the  $\mu$ SAP77016-B17, the user must define the memory area and I/O buffer area necessary for processing. The scratch memory area and static memory area must be separately defined. For the size of each memory area, refer to Table 2-3.

Table 2-3. Symbol Name/Memory Sizes

Symbol Name	Size [Words]	X/Y Plane	Description
scratch_x_area	4756	Х	Scratch area
scratch_y_area	4096	Υ	Scratch area
static_x_area	2048	Х	Static area
static_y_area	5	Υ	Static area

Caution Place the X memory and Y memory areas used for the library in the internal ROM/RAM space.

The size of the scratch memory area and static memory area shown above does not include the audio data and bit stream data buffers. Refer to 2.5.3 I/O buffers.

#### 2.5.1 Scratch area

The scratch area is a memory area that can be discarded when it is not used by the  $\mu$ SAP77016-B17.

The user can use the scratch area freely after encoding processing of one frame.

When the  $\mu$ SAP77016-B17 uses this area again, however, the information set by the user to this area is not guaranteed.

Example LIB\_SCRATCH\_X xramseg

scratch\_x\_area: ds 4756

LIB\_SCRATCH\_Y yramseg scratch\_y\_area: ds 4096

## 2.5.2 Static area

The static area is a memory area that cannot be discarded even when the  $\mu$ SAP77016-B17 does not operate. The user must not use the static area.

If the user manipulates this area after initialization, the correct operation of the  $\mu$ SAP77016-B17 cannot be guaranteed.

Example LIB\_STATIC\_X xramseg

static\_x\_area: ds 2048

LIB\_STATIC\_Y yramseg static\_y\_area: ds 5

#### 2.5.3 I/O buffers

The I/O buffer is an area to which audio data (16-bit linear PCM data) is input and from which bit stream data is output. The user must secure an area for the I/O buffers in X memory.

The user can freely use the I/O buffer area after encoding processing of one frame.

If the audio data or bit stream data area is manipulated during encoding processing, the correct operation is not guaranteed.

Example Necessary I/O buffers

MAIN\_X\_WORK xramseg

sPCM: ds 2048

\_\_BitstreamBuffer: ds 768

Figure 2-3. User-Defined Input Buffer (PCM Buffer)





Figure 2-4. User-Defined Output Buffer (Bit Stream Buffer)



Caution

For mono (when the number of channels is 1), set the size of the PCM buffer to 1024 words or more. Also secure 384 words or more for the bit stream buffer.

For stereo (when the number of channels is 2), set the size of the PCM buffer to 2048 words or more. Also secure 768 words or more for the bit stream buffer.

If a buffer of the necessary size is not secured, the output result cannot be guaranteed.

## **CHAPTER 3 INSTALLATION**

## 3.1 Installation Procedure

The  $\mu$ SAP77016-B17 (AAC encoder middleware) is supplied on a CD-ROM. The procedure for installing the  $\mu$ SAP77016-B17 in the host machine is outlined below.

(1) Set the floppy disk in the floppy disk drive and copy the files to the directory where WB77016 and HSM77016 (DSP tools) are used (e.g. C:\DSPTools).

The following is an example of when files are copied from the Q drive to the C drive.

Q:\>xcopy /s \*.\* c:\DSPTools<CR>

(2) Confirm that the files have been copied. Refer to **1.4.5 Directory configuration** for details on the directories.

C:\>dir c:\DSPTools<CR>

## 3.2 Sample Program Creation Procedure

A sample program is stored in the smp directory.

The sample program operates on HSM77016 (high-speed simulator) Ver. 2.32 or later. Using the timing files described later makes it possible to simulate data I/O. Refer to **APPENDIX SAMPLE PROGRAM SOURCE** regarding timing files.

The following is an explanation of how to build the AAC decoder middleware sample program.

- (1) Start up the WB77016 (workbench) Ver.2.4 or later.
- (2) Open the sample.prj project file.

**Example** Specify sample.prj with the Open Project command on the Project menu.

- (3) Execute Build and confirm that sample. Ink has been created.
  - **Example** The sample. Ink file can be created by selecting the Build All command from the Make menu.
- (4) Start up the HSM77016 (high-speed simulator) Ver.2.32 or later.
- (5) Open the sample.lnk file.
  - **Example** Specify sample.lnk with the Open command on the File menu.
- (6) Open timing files (value.tmg, pcmin.tmg, streamout.tmg).
  - **Example** Specify value.tmg with the Open command on the File menu.

## 3.3 Symbol Naming Conventions

Table 3-1 shows the naming conventions of the symbols used for the  $\mu$ SAP77016-B17. Do not use symbol names in duplicate when other applications are used in combination.

**Table 3-1. Symbol Naming Conventions** 

Classification	Convention
	AACENC_XXXX
constant segment name (ROMSEG/RAMSEG), constant name, variable area name	

Remark XXXX is an alphanumeric character string.

## **CHAPTER 4 SYSTEM EXAMPLE**

## 4.1 Simulation Environment Using Timing File

The simulation environment of the compression processing of the  $\mu$ SAP77016-B17 is shown below. Audio data (16-bit linear PCM data) is input and compressed in 1-frame units, and the compressed data is output.

#### [Software environment]

- High-speed simulator: HSM77016 Ver.2.32 or later
- Sample program: sample.lnk (created in 3.2 Sample Program Creation Procedure)
- Timing file: value.tmg, pcm\_in.tmg, stream\_out.tmg

## 4.2 Operation

- <1> Start up the high-speed simulator.
- <2> Open sample.lnk created in 3.2 Sample Program Creation Procedure.
  - **Example** Specify sample.lnk by clicking 'file  $\rightarrow$  open'.
- <3> Open the timing files (value.tmg, pcm\_in.tmg, stream\_out.tmg).
  - **Example** Specify value.tmg by clicking 'file  $\rightarrow$  open'.
- <4> Execute using Run.

## APPENDIX SAMPLE PROGRAM SOURCE

## A.1 Header File (aacenc.h)

```
#ifndef __aacenc_h
#define __aacenc_h
#define AACENC_STATIC_AREA_X_SIZE 2048
#define AACENC_STATIC_AREA_Y_SIZE 5
#define AACENC_SCRATCH_AREA_X_SIZE 4756
#define AACENC_SCRATCH_AREA_Y_SIZE 4096

#define HeaderSize 7

extrn AACENC_Start
extrn AACENC_Start
extrn AACENC_Encode
extrn AACENC_GetVersion
#endif
```

## A.2 Include File for Sample Program (sample.inc)

```
(1/2)
VECTOR imseg at 0x200
%define (JmpVect(addr))
        jmp addr
        nop
        nop
        nop
%define (NopVect)
        nop
        reti
        nop
        nop
ivReset:
        %JmpVect(StartUp) ;
        %NopVect
        %NopVect
        %NopVect
ivINT1:
        %NopVect
ivINT2:
        %NopVect
ivINT3:
        %NopVect
ivINT4:
        %NopVect
ivINT5:
        %NopVect
ivINT6:
        %NopVect
ivINT7:
        %NopVect
ivINT8:
        %NopVect
ivINT9:
        %NopVect
ivINT10:
        %NopVect
ivINT11:
        %NopVect
ivINT12:
        %NopVect
```

```
(2/2)
%define(Initialize)
      clr (r0)
                          ;
      r1 = r0
      r2 = r0
      r3 = r0
      r4 = r0
      r5 = r0
      r6 = r0
      r7 = r0
      dp0 = r01
      dp1 = r01
      dp2 = r01
      dp3 = r01
      dp4 = r01
      dp5 = r01
      dp6 = r01
      dp7 = r01
      dn0 = r01
      dn1 = r01
      dn2 = r01
      dn3 = r01
      dn4 = r01
      dn5 = r01
      dn6 = r01
      dn7 = r01
      dmx = r01
      dmy = r01
```

32

## A.3 Sample Source File (sample.asm)

(1/5)#include "aacenc.h" LIB\_STATIC\_X xramseg static\_x\_area: AACENC STATIC AREA X SIZE LIB\_STATIC\_Y yramseg AACENC\_STATIC\_AREA\_Y\_SIZE static\_y\_area: ds LIB SCRATCH X xramseg ds scratch\_x\_area: AACENC SCRATCH AREA X SIZE LIB\_SCRATCH\_Y yramseg scratch\_y\_area: ds AACENC\_SCRATCH\_AREA\_Y\_SIZE MAIN X WORK xramseg at 0x6000 1024\*2 sPCM: ds \_\_BitstreamBuffer: ds 2048/2 Header: Header bitrate H: ds 1 Header bitrate L: ds 1 \_Header\_speaker\_config: ds 1 \_Header\_sampling\_freq\_H: ds 1 \_Header\_sampling\_freq\_L: ds 1 \_Header\_header\_type: ds Header mpeg id: \_OutputBufferFlag: ds 1 \_valued: ds 1 \_frame\_number: ds 1 MAIN CTRL WORK xramseg at 0x5ffc \_s: 1 ; Reference value of timing files ds \_stream\_length: ds 1 ; Reference value of timing files ; Reference value of timing files \_FW\_out\_flag: ds 1 \_FW\_run\_flag: ds 1 ; Reference value of timing files #defineHeader bitrate H Header bitrate H:x #defineHeader\_bitrate\_L \_Header\_bitrate\_L:x \_Header\_speaker\_config:x #defineHeader\_speaker\_config #defineHeader\_sampling\_freq\_H \_Header\_sampling\_freq\_H:x #defineHeader\_sampling\_freq\_L \_\_Header\_sampling\_freq\_L:x #defineHeader\_header\_type \_Header\_header\_type:x #defineHeader\_mpeg\_id \_Header\_mpeg\_id:x #defineOutputBufferFlag \_OutputBufferFlag:x #definevalued \_valued:x \_frame\_number:x #defineframe\_number #defines s:x #definestream\_length \_stream\_length:x #defineFW out flag \_FW\_out\_flag:x #defineFW\_run\_flag \_FW\_run\_flag:x

33

(2/5)

```
#include " sample.inc"
MAIN imseg at 0x240
StartUp:
     %Initialize
     clr (r0)
     dp0 = __BitstreamBuffer
     rep 2048/2
                   *dp0++ = r0h
     dp0 = sPCM
     rep 1024*2
                   *dp0++ = r0h
     dp4 = 0x4000
     rep 0x2000
                   *dp4++ = r0h
     *OutputBufferFlag = r0h
     *frame_number = r0h
     *valued = r0h
     *stream length = r0h
     clr (r0)
                                               ;run_flag = 0
     *FW_run_flag = r0h
     r0 = *FW_run_flag
                                               ;while (run_flag == 0) {}
     if (r0 == 0) jmp $-1
     ;; header analysis ;; (MSB) ;; 22+2+4+6+2+8 = 44byte -> 22word
     dp0 = sPCM
     rep 22/2
                                               ;fread (header, 1, 22, fi)
                  r0 = *dp0++
                  r0 = *dp0++
                                               ;fread (&s, 1, 2, fi)
     *s = r0h
     r1 = r0 sra 16
                                               ;Header.speaker_config = (s == 1) ? 0 : 1
     r1 = r1 - 1
     clr (r0)
     if (r1 != 0) r0 = r0 + 1
     *Header_speaker_config = r0l
                   r0 = *dp0++
                                              ;fread (&i, 1, 4, fi)
                   r0l = *dp0++
     *Header_sampling_freq_H = r0l
                                              ;Header.sampling_freq = i
     *Header_sampling_freq_L = r0h
                                               ;fread (tmp, 1, 6+2+8, fi)
     clr (r0)
     r01 = 64000
                                               ;64kbps
```

(3/5)

```
nop;
     *Header_bitrate_H = r0h
     *Header bitrate L = r0l
     r01 = 1
                                  ;MPEG-2 AAC
     *Header_mpeg_id = r01
     r01 = 2
                                  ;header_type = 2
     *Header_header_type = r01
     r01 = Header
                                  ;ret = AACENC_Start (&Header, BitstreamBuffer)
     r1l = __BitstreamBuffer
     r2l = static_x_area
     r3l = scratch_x_area
     r4l = static_y_area
     r5l = scratch_y_area
     call AACENC_Start
     if (r0 < 0) jmp _exit
                          ;CopyOutputBuffer (ret, BitstreamBuffer)
     call CopyOutputBuffer
                                  ;while (1) {
_while1:
    clr (r0)
                                 ; run_flag = 0
     *FW_run_flag = r0h
                                  ; while (run_flag == 0) {}
     r0 = *FW_run_flag
    if (r0 == 0) jmp $-1
     r01 = Header
                                  ; ret = AACENC_Encode (&Header, sPCM, BitstreamBuffer)
     r11 = sPCM
    r2l = __BitstreamBuffer
    r3l = static_x_area
     r4l = static_y_area
     call AACENC Encode
     if (r0 < 0) jmp _exit
                                 ; if (ret < 0) exit(ret)
     call CopyOutputBuffer
                                 ; CopyOutputBuffer (ret, BitstreamBuffer)
     r1l = *frame_number
                               ; frame_numfer++
     r1 = r1 + 1
     *frame number = r1l
     jmp _while1
                                 ;}
_break1:
     dp0 = sPCM
                                  ;Clear (0) sPCM area
    clr (r0)
                                  ;for (i = 0; i < 2048; i++) {
     rep 2048
                                  ; sPCM[i] = 0
               *dp0++ = r0h
                                  ; }
```

(4/5)

```
r01 = Header
                                       ;ret = AACENC_Encode (&Header, sPCM, BitstreamBuffer)
     r11 = sPCM
     r2l = __BitstreamBuffer
     r3l = static_x_area
     r4l = static_y_area
     call AACENC_Encode
     if (r0 < 0) jmp _exit
                                       ;if (ret < 0) exit(ret)
     call CopyOutputBuffer
                                       ;CopyOutputBuffer (ret, BitstreamBuffer)
     r01 = Header
                                       ;ret = AACENC Encode (&Header, sPCM, BitstreamBuffer)
     r11 = sPCM
                                        ;
     r2l = __BitstreamBuffer
     r3l = static_x_area
     r4l = static_y_area
     call AACENC_Encode
                                      ;if (ret < 0) exit(ret)
     if (r0 < 0) jmp _exit
     call CopyOutputBuffer
                                       ;CopyOutputBuffer (ret, BitstreamBuffer)
     r01 = Header
                                       ;ret = AACENC Encode (&Header, sPCM, BitstreamBuffer)
     r11 = sPCM
     r21 = __BitstreamBuffer
     r3l = static_x_area
     r4l = static_y_area
     call AACENC_Encode
                                      ;if (ret < 0) exit(ret)
     if (r0 < 0) jmp _exit
     call CopyOutputBuffer
                                      ;CopyOutputBuffer (ret, BitstreamBuffer)
     r0 = *OutputBufferFlag
     if (r0 == 0) jmp _exit
                r0 = *valued
                *0x4000:y = r0h
                r01 = 1
                *stream_length = r01
                clr (r1)
                *FW_out_flag = r1h
                r1 = *FW_out_flag
                if (r1 == 0) jmp $-1
_exit:
    clr (r0)
    r01 = 0x2222
                                       ; length = 0x2222
     *stream_length = r01
     *FW_out_flag = r0h
                                       ;out_flag = 0
     *FW_run_flag = r0h
                                       ;run_flag = 0
     jmp StartUp
```

(5/5)

```
;; Copy from BitstreamBuffer to output buffer ;;
CopyOutputBuffer:
    if (r0 == 0) ret
     dp4 = 0x4000
                                     ; wpt = 0x4000
                                    ;rpt = BitstreamBuffer
     dp0 = __BitstreamBuffer
     r2 = *OutputBufferFlag
                                    ;if (OutputBufferFlag == 0) {
     if (r2 != 0) jmp _L1
     r1 = r0 sra 1
                                    ; count = len >> 1
     *stream_length = r1l
     r2 = r0 \& 1
     loop r11 {
                                     ; for ( ; count > 0; count--) {
                 r1 = *dp0++
                                    ; tmp = *rpt++
                 *dp4++ = r1h
                                          *wpt++ = tmp
                                    ;
                                     ; }
     *OutputBufferFlag = r2l
                                    ;
                                    ; if (len & 1) {
     if (r2 == 0) jmp _L2
                r1 = *dp0
                                    ; valued = *rpt
                 *valued = r1h ; }
     jmp _L2
                                     ;}
_L1:
                                     ;else {
     r1 = r0 sra 1
                                     ; count = len >> 1
                                    ; if (len & 1)
     r2 = r0 \& 1
    if (r2 != 0) r1 = r1 + 1
                                    ; count++
     *stream_length = r1l
     r0 = *valued
                                    ; tmp = valued << 8
     r0 = r0 sra 8
     loop r11 {
                                    ; for ( ; count > 0; count--) {
                 r01 = *dp0++
                                        tmp |= *rpt++
                                    ;
                                    ; tmp <<= 8
                 r0 = r0 \ sll \ 8
                 *dp4++ = r0h
                                    ;
                                          *wpt++ = (tmp >> 16)
                 r0 = r0 sll 8
                                           tmp <<= 8
                                     ;
                                     ; }
     r0 = r0 sll 8
     *valued = r0h
                                    ; valued = tmp >> 16
     clr (r1)
                                     ; *wpt = valued
     if (r2 == 0) r1 = r1 + 1
     *OutputBufferFlag = r1l
_L2:
                                      ;}
     clr (r0)
     *FW_out_flag = r0l
     r0 = *FW_out_flag
     if (r0 == 0) jmp $-1
     ret
                                     ;return
end
```

## A.4 Timing File for Parameter Information (value.tmg)

```
global s, FW_run_flag, FW_out_flag, stream_length, pcm_start, stream_start
global out44_128, out44_96, out44_80, out44_64
global out32 96, out32 64, out32 48, out32 40
global flag01, flag02, flag03, flag04, flag05
global flag08, flag09, flag12, flag13, flag19
global flag21
                      = 0x5ffc
set s
set stream_length = 0x5ffd
set FW_out_flag = 0x5ffe
set FW_run_flag = 0x5fff
set pcm_start
                    = 0x6000
set stream start = 0x4000
set out44 128 = 1 << 7
set out44_96 = 1 << 6
set out44 80 = 1 << 5
set out44 64 = 1 << 4
set out32 96 = 1 << 3
set out32 64 = 1 << 2
set out32 48 = 1 << 1
set out32_40 = 1 << 0
set flag01 = 0
set flag02 = 0
set flag03 = 0
set flag04 = 0
set flag05 = 0
set flag08 = 0
set flag09 = 0
set flag12 = 0
set flag13 = 0
set flag19 = 0
set flag21 = 0
set flag01 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag02 = out44 128 | out44 96 | out44 80 | out44 64 | out32 96 | out32 64 | out32 48 | out32 40
set flag03 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag04 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag05 = out44 128 | out44 96 | out44 80 | out44 64 | out32 96 | out32 64 | out32 48 | out32 40
set flag08 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag09 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag12 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag13 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag19 = out44_128 | out44_96 | out44_80 | out44_64 | out32_96 | out32_64 | out32_48 | out32_40
set flag21 = out44 128 | out44 96 | out44 80 | out44 64 | out32 96 | out32 64 | out32 48 | out32 40
end
```

## A.5 Timing File for Data Input (pcm\_in.tmg)

(1/2)global s, FW\_run\_flag, FW\_out\_flag, stream\_length, pcm\_start global out44\_128, out44\_96, out44\_80, out44\_64 global out32\_96, out32\_64, out32\_48, out32\_40 global flag01, flag02, flag03, flag04, flag05 global flag08, flag09, flag12, flag13, flag19 global flag21 local size, data, pcm local SZ local bitrate local addr set addr = 0x27csub hanten ; (data) set data = ((data >> 8) & 0xff) | ((data & 0xff) << 8) endsub sub WriteData hanten set \*pcm:x = dataset pcm = pcm + 1endsub sub Writting ; (size, sz) local tmp set pcm = pcm\_start if (size >= sz) rept sz input data WriteData endrept set size = size - sz else set tmp = sz - sizerept size input data WriteData endrept set data = 0 rept tmp WriteData endrept set size = 0endif endsub

39

(2/2)

```
sub wave2stream
        input format hex
        input size
        set *FW_run_flag:x = 1
        wait cond (*FW_run_flag:x != 1)
        set sz = 22
        Writting
        if (*s:x == 1)
                 set sz = 1024
        else
                 set sz = 2048
        endif
        set *FW_run_flag:x = 1
        wait cond ip == addr
        set r0 = bitrate
        do
                 set *FW_run_flag:x = 1
                 wait cond (*FW_run_flag:x != 1)
                 exit (size < sz)
                 Writting
        enddo
        set *FW_run_flag:x = -1
        wait cond (*FW_run_flag:x != -1)
endsub
;;; Wait for initialize ;;;
wait 1
if (flag02)
        if (flag02 & out32_40)
                 ;;; 02.wav / 32kHz / 40kbps ;;;
                 open input "02_32.dat"
                 set bitrate = 40000
                 wave2stream
                 close input
        endif
endif
break
end
```

## A.6 Timing File for Data Output (stream\_out.tmg)

```
global FW_out_flag, stream_length, stream_start
global out44_128, out44_96, out44_80, out44_64
global out32_96, out32_64, out32_48, out32_40
global flag01, flag02, flag03, flag04, flag05
global flag08, flag09, flag12, flag13, flag19
global flag21
sub wave2stream2
        local
                 data, rpt, length
        output #10 format dec
        do
                 set *FW_out_flag:x = 1
                 wait cond *FW out flag:x != 1
                 set length = *stream_length:x
                 exit length >= 0x2000
                 if (length)
                          set rpt = stream_start
                          rept length
                              set data = *rpt:y
                              output #10 data
                              set rpt = rpt + 1
                          endrept
                 endif
        enddo
endsub
;;; main ;;;
wait 1
if (flag02)
        ;;; 02.wav ;;;
        if (flag02 & out32 40)
                 open output #10 "02_32_40.dat"
                 wave2stream2
                 close output #10
        endif
endif
end
```

[MEMO]