Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1st, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.



Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights
 of third parties by or arising from the use of Renesas Electronics products or technical information described in this document.
 No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights
 of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



M16C/80 Group

Operation of A-D Converter (in repeat mode)

1.0 Abstract

In repeat mode, choose functions from those listed in Table 1. Operations of the circled items are described below.

Table 1. Choosed functions

Item	Set-up		Item	Set-up	
Operation clock	0	Divided-by-4 fAD / divided- by-2 fAD / fAD	Expanded analog input pin	0	Not used
					Either ANEX0 pin or ANEX1 pin
Resolution	0	8-bit / 10-bit		'	
Analog input pin	0	One of ANo pin to AN7 pin			External operation amplifier connection mode
Trigger for starting A-D conversion	0	Software trigger	Sample & Hold		Not activated
		Trigger by ADTRG		0	Activated

2.0 Introduction

Operation (1) Setting the A-D conversion start flag to "1" causes the A-D converter to start operating.

- (2) After the first conversion is completed, the content of the successive comparison register (conversion result) is transmitted to A-D register i. The A-D conversion interrupt request bit does not change.
- (3) The A-D converter continues operating until the A-D conversion start flag is set to "0" by software. The conversion result is transmitted to A-D register i every time a conversion is completed.

Note

• In repeat mode, the A-D conversion interrupt request bit does not change. By using Timer, it is possible to make it synchronize with the timing which A-D conversion completes, and to read conversion results repeatedly.

Figure 1 shows the operation timing





Figure 1. Operation timing of repeat mode





3.0 Set-up procedure





4.0 Programming Code

```
M16C/80 Program Collection
  FILE NAME : rjj05b0479_src.a30
  CPU : M16C/80 Group
 FUNCTION : Operation of A-D Converter
         (in repeat mode)
 HISTORY : 2004.02.02 Ver 1.00
  Copyright(C)2003, Renesas Technology Corp.
  Copyright(C)2003, Renesas Solutions Corp.
  All rights reserved.
.LIST OFF ;Stops outputting lines to the assembler list file .INCLUDE sfr80100.inc ;Reads the file that defined SFR
           ON
                    ;Starts outputting lines to the assembler list file
    .LIST
Symbol definition
.EQU 000400H ;Start address of RAM
RAM_TOP
     .EQU 002BFFH ;End address of RAM .EQU 0FFC000H ;Start address of ROM
RAM END
ROM_TOP
            0FFFFDCH
                    ;Start address of fixed vector
FIXED_VECT_TOP .EQU
Program area
Start up
.SECTION PROGRAM, CODE ; Declares section name and section type
           ROM_TOP
                    ;Declares start address
RESET:
         #RAM_END+1, ISP ;Sets initial value in stack pointer
    ; Sets Processor mode, System clock and Main clock division
    MOV.B #03H, prcr ;Removes protect
    MOV.B
         #10000000B, pm0
                    ; Single-chip mode
    MOV.B
         #11000000B, pm1
                    ; Flash memory version
    MOV.B
         #00001000B, cm0
                    ; Xcin-Xcout High
    MOV.B #00100000B, cml; Xin-Xout High
    MOV.B #00010010B, mcd; No division mode
    MOV.B #00H, prcr
                    ;Protects all registers
```



Operation of A-D Converter (in repeat mode)

```
A-D Converter (in repeat mode)
; Selecting sample and hold
      MOV.B #0000001B, adcon2
;
                    +----;A-D conversion method select bit
                              (1:With sample and hold)
      ; Setting A-D control register 0 and A-D control register 1
             #10001000B, adcon0
               |||||+++----;Analog input pin select bit (000:ANO is selected)
               |||++----;Repeat mode is selected
               | | +----; Trigger select bit (0:Software trigger)
               |+----;A-D conversion start flag (0:A-D conversion disabled)
               +----; Frequency select bit 0 (1:fAD/2 is selected)
              #00101000B, adcon1
      MOV.B
               |||||++----;Invalid in Repeat mode
                |||||+----;A-D operation mode select bit1
               11111
                             (Must always be "0" in repeat mode)
               |||||+-----;8/10-bit mode select bit (1:10-bit mode)
               |||+----;Frequency select bit 1 (0:fAD/2 or fAD/4 is selected)
               | | +----; Vref connect bit (1: Vref connected) (Note)
               ++----;External op-amp connection mode bit
                              (00:ANEX0 and ANEX1 are not used) (Note)
      ; Setting the direction register of the relevant port to input
             pd10_0
                             ;ANO(P100):Analog input pin
      ; (Note) Setting function select register B3 (ANEXO & ANEX1 are not used)
                      ;P95:Input peripheral function enabled
           ps13 5
                             ;P96:Input peripheral function enabled
           ps13_6
      Start A-D conversion
      ; (Note) When the Vref connection bit is changed from 0 to 1,
            start A-D conversion after an elapsing of 1 us or longer.
      MOV.W #10, R0 ; 10 * 2cy = 20cy = 1 us or longer (@20MHz)
PRE_START:
      NOP
      ADJNZ.W #-1, R0, PRE_START
START AD:
      ; Setting A-D conversion start flag
      BSET adst
                            ; A-D conversion started
REPEAT_AD_CNV:
      ;
      ; Processing of reading A-D conversion result
      ; depending on the application program.
      JMP
            REPEAT AD CNV
;-----
      Stop A-D conversion
STOP_AD:
     BCLR
             adst
                            ; A-D conversion stop
STOPPED_AD:
     JMP STOPPED_AD
```



```
Dummy interrupt processing program
dummy:
Setting of fixed vector
     .SECTION F_VECT, ROMDATA
    .ORG
           FIXED_VECT_TOP
    .LWORD dummy
                 ;Undefined instruction
     .LWORD
           dummy
                 ;Overflow
     .LWORD
           dummy
                 ;BRK instruction execution
           dummy
     .LWORD
                 ;Address match
     .LWORD
           dummy
                 ;Watchdog timer
     .LWORD
           dummy
     .LWORD
           dummy
     .LWORD
           dummy
                 ;NMI
           RESET
     .LWORD
                 ;Reset
     .END
```



5.0 Reference

Renesas Technology Corporation Semiconductor Home page

http://www.renesas.com/

Technical Support

E-mail: support_apl@renesas.com

Data Sheet

M16C/80 group Rev. E3

(Use the latest version on the Home page: http://www.renesas.com/)

TECHNICAL UPDATE/TECHNICAL NEWS

(Use the latest information on the Home page: http://www.renesas.com/)



-Keep safety first in your circuit designs!-

• Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

- These materials are intended as a reference to assist our customers in the selection
 of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any
 other rights, belonging to Renesas Technology Corporation or a third party.
- Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
- All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein. The information described here may contain technical inaccuracies or typographical errors.

Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.

Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (http://www.renesas.com).

- When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
- Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
- The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
- If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination. Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
- Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.