

RX220 Group

R01AN2234EJ0100 Rev. 1.00 Oct. 1, 2014

Application Example of Exclusive Operation of Two Motors by One Set of Complementary PWM Outputs

Abstract

This application note describes an example of exclusive operation of two motors by one set of three-phase complementary pulse width modulation (PWM) outputs using multi-function timer pulse unit 2 (MTU).

Products

- RX220 Group, 100-pin version, ROM capacity: 64 KB to 256 MB
- RX220 Group, 64-pin version, ROM capacity: 32 KB to 256 MB
- RX220 Group, 48-pin version, ROM capacity: 32 KB to 256 MB

When using this application note with other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU.

Contents

| 1. | Spe | ecific | ications | | |
|----|-----|--------|------------------------------------|----|--|
| 2. | Ор | eratio | on Confirmation Conditions | 4 | |
| 3. | Re | feren | ice Application Note | 4 | |
| 4. | Ha | rdwa | re | 5 | |
| | 4.1 | Har | dware Configuration | 5 | |
| | 4.2 | Pins | s Used | 5 | |
| 5. | Sof | ftwar | e | 6 | |
| | 5.1 | Оре | eration | 7 | |
| | 5.2 | File | Composition | 8 | |
| | 5.3 | Opt | ion-Setting Memory | 8 | |
| | 5.4 | Cor | nstants | 9 | |
| | 5.5 | Var | iables | 9 | |
| | 5.6 | Fun | ctions | 10 | |
| | 5.7 | Fun | ction Specifications | 11 | |
| | 5.8 | Flov | vcharts | 14 | |
| | 5.8 | 3.1 | Main Processing | 14 | |
| | 5.8 | 3.2 | Port Initialization | 15 | |
| | 5.8 | 3.3 | Peripheral Function Initialization | | |
| | 5.8 | 3.4 | MTU Initialization | 17 | |
| | 5.8 | 3.5 | PWM Output Pin Switching. | 19 | |
| | 5.8 | 3.6 | PWM Output Pin Group 0 Settings | 20 | |
| | 5.8 | 3.7 | PWM Output Pin Group 1 Settings | 21 | |
| | 5.8 | 8.8 | Switch Input Determination | 22 | |
| | 5.8 | 3.9 | MTU3.TGIA3 Interrupt Handler | 23 | |
| 6. | Saı | mple | Code | 24 | |
| 7 | Do | foron | aco Documento | 24 | |

1. Specifications

Using the MTU's complementary PWM mode 3, three-phase complementary PWM waveforms and a toggle waveform synchronized with the PWM cycle are output. A dead time (period for preventing a short circuit) is specified for the complementary PWM outputs to ensure a non-overlapping relationship between the positive-phase and negative-phase pulses.

After a reset is released, complementary PWM waveforms are output on PWM output pin group 0 (PC5, PC4, PB3, PB1, PC2, and PC3). When a switch input is detected, the waveforms are output on PWM output pin group 1 (PB7, PB6, PE2, PE1, PE3, and PE4). Thereafter, the waveforms are output alternately from PWM output pin group 0 and group 1 each time a switch input is detected.

• PWM cycle: 200 μs

• PWM duty: Changes each PWM cycle (initial value: 50%)

• PWM active level: Low level

Dead time: 4 μs

Table 1.1 Peripheral Functions and Their Applications

| Peripheral Function | Application |
|------------------------|--|
| MTU2a channel 3 (MTU3) | Complementary PWM output and PWM cycle toggle output |
| MTU2a channel 4 (MTU4) | Complementary PWM output |
| MPC | Complementary PWM output pin switching |




Figure 1.1 Block Diagram

2. Operation Confirmation Conditions

The sample code accompanying this application note has been run and confirmed under the conditions below.

Table 2.1 Operation Confirmation Conditions

| ltem | Contents |
|------------------------------------|--|
| Microcontroller used | R5F52206BDFP (RX220 Group) |
| Operating frequency | Main clock: 20 MHz |
| | System clock (ICLK): 20 MHz (main clock divided by 1) |
| | Peripheral module clock B (PCLKB): 20 MHz (main clock divided by 1) |
| Operating voltage | 5.0 V |
| Integrated development environment | Renesas Electronics Corporation High-performance Embedded Workshop Version 4.09.01 |
| C compiler | Renesas Electronics Corporation C/C++ Compiler Package for RX Family V.1.02 Release 01 |
| | Compiler options -cpu=rx200 -output=obj="\$(CONFIGDIR)\pmax\pmax\pmax\pmax(FILELEAF).obj" -debug -nologo (The integrated development environment default settings are used.) |
| iodefine.h version | Version 1.0a |
| Endian order | Little endian |
| Operating mode | Single-chip mode |
| Processor mode | Supervisor mode |
| Sample code version | Version 1.00 |
| Board used | Renesas Starter Kit for RX220 (part number: R0K505220S000BE) |

3. Reference Application Note

For additional information associated with this document, refer to the following application note.

• RX220 Group: Initial Setting, Rev. 1.10 (R01AN1494EJ)

The initial setting functions in the reference application notes are used in the sample code in this application note. The revision numbers of the reference application note is current as of the publication of this application note. However, the latest version is always recommended. Visit the Renesas Electronics Corporation website to check for and download the latest version.

4. Hardware

4.1 Hardware Configuration

Figure 4.1 shows a connection example.




Figure 4.1 Connection Example

4.2 Pins Used

Table 4.1 lists the pins used and their functions.

Table 4.1 Pins Used and Their Functions

| Pin Name | I/O | Function |
|-------------|--------|--|
| P34 | Input | Switch input for changing PWM output pins |
| P14/MTIOC3A | Output | PWM cycle toggle output |
| PC5/MTIOC3B | Output | PWM output 1 (positive-phase) PWM output pin group 0 |
| PC4/MTIOC3D | Output | PWM output 1 (negative-phase) PWM output pin group 0 |
| PB3/MTIOC4A | Output | PWM output 2 (positive-phase) PWM output pin group 0 |
| PB1/MTIOC4C | Output | PWM output 2 (negative-phase) PWM output pin group 0 |
| PC2/MTIOC4B | Output | PWM output 3 (positive-phase) PWM output pin group 0 |
| PC3/MTIOC4D | Output | PWM output 3 (negative-phase) PWM output pin group 0 |
| PB7/MTIOC3B | Output | PWM output 1 (positive-phase) PWM output pin group 1 |
| PB6/MTIOC3D | Output | PWM output 1 (negative-phase) PWM output pin group 1 |
| PE2/MTIOC4A | Output | PWM output 2 (positive-phase) PWM output pin group 1 |
| PE1/MTIOC4C | Output | PWM output 2 (negative-phase) PWM output pin group 1 |
| PE3/MTIOC4B | Output | PWM output 3 (positive-phase) PWM output pin group 1 |
| PE4/MTIOC4D | Output | PWM output 3 (negative-phase) PWM output pin group 1 |

5. Software

After the initial settings, a toggle waveform synchronized with the PWM cycle, and three-phase complementary PWM waveforms on PWM output pin group 0, are output.

When a switch input is detected, the complementary PWM waveform output destination is switched between PWM output pin group 0 and group 1 alternately. The carrier cycle of the PWM output is assumed to be 200 μ s. This interrupt every 200 μ s is used to generate 5 ms of switch input read cycle, and an input is determined when the switch input level matches three times in succession.

The peripheral function settings used are listed below.

MTU (MTU3 and MTU4)

• Counter clock: PCLKB/1 rising edge

Operation mode: Complementary PWM mode 3 (transfer at crest and trough)

• Dead time: 4 µs

• Carrier cycle (PWM cycle): 200 μs (carrier frequency: 5 kHz)

• TDDR register: Sets offset value of MTU4.TCNT and MTU3.TCNT (dead time)

(setting value: $80 = 4 \mu s / \text{counter clock cycle}$)

• TCDR register: Sets MTU4.TCNT upper limit value (1/2 of carrier cycle)

(setting value: $2000 = 100 \mu s / \text{counter clock cycle}$)

• TCBR register: Operates as buffer register of TCDR register

• MTU3.TGRA register: Sets MTU3.TCNT upper limit value (1/2 of carrier cycle + dead time)

(setting value: 2080 = 2000 + 80)

• MTU3.TGRB register: Sets duty of PWM output 1 (initial value: 50%)

(setting value: 1000 = 2000 / 2)

MTU3.TGRC register: Operates as buffer register of MTU3.TGRA register
 MTU3.TGRD register: Operates as buffer register of MTU3.TGRB register
 MTU4.TGRA register: Sets duty of PWM output 2 (initial value: 50%)

(setting value: 1000 = 2000 / 2)

• MTU4.TGRB register: Sets duty of PWM output 3 (initial value: 50%)

(setting value: 1000 = 2000 / 2)

MTU4.TGRC register: Operates as buffer register of MTU4.TGRA register
 MTU4.TGRD register: Operates as buffer register of MTU4.TGRB register

• Positive-phase output levels: Initial output: High

Active level: Low

Compare match output (up counter): Low Compare match output (down counter): High

• Negative-phase output levels: Initial output: High

Active level: Low

Compare match output (up counter): High Compare match output (down counter): Low

• PWM sync output: Toggle output enabled

PWM output pin 1: MTIOC3B and MTIOC3D pin output enabled
 PWM output pin 2: MTIOC4A and MTIOC4C pin output enabled
 PWM output pin 3: MTIOC4B and MTIOC4D pin output enabled

• Counter clearing: Clearing TCNT disabled

• Interrupt: Use TGR interrupt request A (MTU3.TGIA3)

5.1 Operation

(1) Initial Settings

After the initial settings, a toggle waveform synchronized with the PWM cycle, and three-phase complementary PWM waveforms on PWM output pin group 0, are output.

(2) TGIA3 Interrupt Handler

The interrupt handler for TGIA3, which is generated every 200 µs, increments the switch read cycle counter for measuring 5 ms intervals by 1, and changes the PWM output duty.

(3) Switch Input Determination

When the switch input level, which is read every 5 ms, matches three times consecutively, the switch input determination flag is set to 1.

(4) PWM Output Pin Group Switching

When the switch input determination flag is set to 1, PWM output pin group 0 is set as general input ports and group 1 is set as PWM output pins. The output of PWM output pin group 0 becomes high-impedance, and complementary PWM waveforms are output on group 1.

Figure 5.1 is a timing chart.




Figure 5.1 Timing Chart

5.2 **File Composition**

Table 5.1 lists the files used in the sample code. Files generated by the integrated development environment are not included in this table.

Table 5.1 Files Used in the Sample Code

| File Name | Outline | Remarks |
|----------------------------|--|---------|
| main.c | Main processing | |
| r_init_stop_module.c | Stop processing for peripheral functions that are active after a reset | |
| r_init_stop_module.h | r_init_stop_module.c header file | |
| r_init_non_existent_port.c | Nonexistent port initialization | |
| r_init_non_existent_port.h | r_init_non_existent_port.c header file | |
| r_init_clock.c | Clock initialization | |
| r_init_clock.h | r_init_clock.c header file | |

5.3 **Option-Setting Memory**

Table 5.2 lists the option-setting memory configured in the sample code. When necessary, set a value suited to the user system.

Table 5.2 Option-Setting Memory Configured in the Sample Code

| Symbol | Address | Setting Value | Contents |
|--------|--------------------------|---------------|--|
| OFS0 | FFFF FF8Fh to FFFF FF8Ch | FFFF FFFFh | IWDT is stopped after a reset. |
| OFS1 | FFFF FF8Bh to FFFF FF88h | FFFF FFFFh | Voltage monitor 0 reset is disabled after a reset. HOCO oscillation is disabled after a reset. |
| MDES | FFFF FF83h to FFFF FF80h | FFFF FFFFh | Little endian |

5.4 Constants

Table 5.3 lists the constants used in the sample code.

Table 5.3 Constants Used in the Sample Code

| Constant Name | Setting Value | Contents |
|---------------|------------------|---|
| SW_NUM | 3 | Switch match determination count |
| SW_CYCLE | 25 | Switch read cycle: 5 ms = PWM cycle (200 µs) × 25 |
| LOW | 0 | Low level |
| HIGH | 1 | High level |
| PWM_GROUP_0 | 0 | PWM output pin group 0 |
| PWM_GROUP_1 | 1 | PWM output pin group 1 |
| PWM_DEAD_TIME | 80 | Dead time: 4 µs |
| | | = MTU counter clock cycle (1/20 MHz) × 80 |
| PWM_CYCLE | 2000 | 1/2 of carrier cycle: 100 μs |
| | | = MTU counter clock cycle (1/20 MHz) × 2000 |
| PWM_MAX | (PWM_CYCLE | MTU3.TCNT upper limit value: 104 μs |
| | + PWM_DEAD_TIME) | |
| PWM_DUTY_50 | (PWM_CYCLE / 2) | PWM duty setting value: 50% |
| PWM_DUTY_ADD | 0 | PWM duty setting value state: Add |
| PWM_DUTY_SUB | 0 | PWM duty setting value state: Subtract |

5.5 Variables

Table 5.4 lists the global variables.

Table 5.4 Global Variables

| Type | Variable Name | Contents | Function Used |
|----------|----------------|---|------------------|
| uint8_t | sw_cycle_cnt | Switch read cycle counter for measuring | main |
| | | 5 ms intervals | Excep_MTU3_TGIA3 |
| uint8_t | sw_match_cnt | Switch match counter | sw_input_check |
| uint8_t | sw_level_last | Switch previous level | sw_input_check |
| uint8_t | sw_level_fix | Switch determination level | sw_input_check |
| uint8_t | sw_fix_flag | Switch input determination flag | main |
| | | 0: Not determined | sw_input_check |
| | | 1: Determined | |
| | | (switch input falling edge detected) | |
| uint8_t | pwm_pin | PWM output pin | pwm_pin_change |
| uint8_t | pwm_duty_state | PWM duty setting value state | Excep_MTU3_TGIA3 |
| uint16_t | pwm_1_duty | PWM output 1 duty setting value | Excep_MTU3_TGIA3 |
| uint16_t | pwm_2_duty | PWM output 2 duty setting value | Excep_MTU3_TGIA3 |
| uint16_t | pwm_3_duty | PWM output 3 duty setting value | Excep_MTU3_TGIA3 |

RENESAS

5.6 Functions

Table 5.5 lists the functions used in the sample code.

Table 5.5 Functions Used in the Sample Code

| Function Name | Outline |
|------------------------|---|
| main | Main processing |
| port_init | Port initialization |
| R_INIT_StopModule | Stop processing for active peripheral functions after a reset |
| R_INIT_NonExistentPort | Nonexistent port initialization |
| R_INIT_Clock | Clock initialization |
| peripheral_init | Peripheral function initialization |
| mtu_init | MTU initialization |
| pwm_pin_change | PWM output pin switching |
| pwm_pin_group_0 | PWM output pin group 0 settings |
| pwm_pin_group_1 | PWM output pin group 1 settings |
| sw_input_check | Switch input determination |
| Excep_MTU3_TGIA3 | MTU3.TGIA3 interrupt handler |

5.7 **Function Specifications**

The following tables list the sample code function specifications.

main

Outline Main processing

Header None

Declaration void main(void)

After initialization, determine the input level of the switch input for changing PWM **Description**

output pin group every 5 ms. When the switch input determination flag is set to 1,

change the PWM output pins.

Arguments None **Return Value** None

port_init

Port initialization **Outline**

Header None

Declaration void port_init(void) Initialize the ports. Description

Arguments None **Return Value** None

R_INIT_StopModule

Outline Stop processing for active peripheral functions after a reset

Header r init stop module.h

Declaration void R_INIT_StopModule(void)

Configure the setting to enter the module stop-state. Description

Arguments None **Return Value** None

Transition to the module-stop state is not performed in the sample code. Refer to the Remarks

application note RX220 Group: Initial Setting, Rev. 1.10, for details of this function.

R_INIT_NonExistentPort

Outline Nonexistent port initialization Header r_init_non_existent_port.h

Declaration void R INIT NonExistentPort(void)

Initialize port direction registers for ports that do not exist in products with less than **Description**

100 pins.

Arguments None **Return Value** None

Remarks The number of pins in the sample code is set for the 100-pin package

> (PIN SIZE = 100). After this function is called, when writing in byte units to the PDR registers that have nonexistent ports, set the bits corresponding to nonexistent ports as follows: set the I/O select bits to 1 and set the output data store bits to 0. Refer to the application note RX220 Group: Initial Setting, Rev. 1.10, for details of this

function.

R INIT Clock

Outline Clock initialization Header r_init_clock.h

Declarationvoid R_INIT_Clock(void)DescriptionInitialize the clock.

Arguments None Return Value None

Remarks The sample code selects processing which uses PLL as the system clock without

using the sub-clock. Refer to the application note RX220 Group: Initial Setting, Rev.

1.10, for details of this function.

peripheral_init

Outline Peripheral function initialization

Header None

Declaration void peripheral_init(void)

Description Initialize the peripheral functions used by the sample code.

Arguments None Return Value None

mtu init

Outline MTU initialization

Header None

Declaration void mtu_init(void)

Description Initialize the MTU (MTU3 and MTU4).

Arguments None Return Value None

pwm_pin_change

Outline PWM output pin switching

Header None

Declaration void pwm_pin_change(void)

Description Switch alternately between PWM output pin group 0 and group 1.

Arguments None Return Value None

pwm_pin_group_0

Outline PWM output pin group 0 settings

Header None

Declaration void pwm_pin_group_0(void)

Description Change the PWM output pins from group 1 to group 0.

Arguments None Return Value None

| _pwm_pin_group_1 | |
|------------------|---|
| Outline | PWM output pin group 1 settings |
| Header | None |
| Declaration | void pwm_pin_group_1(void) |
| Description | Change the PWM output pins from group 0 to group 1. |
| Arguments | None |
| Return Value | None |
| | |

| sw_input_check | |
|----------------|---|
| Outline | Switch input determination |
| Header | None |
| Declaration | void sw_input_check(void) |
| Description | Determine the switch input level. Compare the current level to the previous level, and determine the input level when the levels match three times consecutively. When the determination level is changed from high to low, set the switch input determination flag to 1. |
| Arguments | None |
| Return Value | None |

| Excep_MTU3_TGIA3 | |
|------------------|---|
| Outline | MTU3.TGIA3 interrupt handler |
| Header | None |
| Declaration | void Excep_MTU3_TGIA3(void) |
| Description | Change the duty of the PWM output, and update the switch read cycle counter for measuring 5 ms intervals. |
| Arguments | None |
| Return Value | None |

5.8 Flowcharts

5.8.1 Main Processing

Figure 5.2 is a flowchart of the main processing routine.




Figure 5.2 Main Processing

5.8.2 Port Initialization

Figure 5.3 is a flowchart of the port initialization routine.




Figure 5.3 Port Initialization

5.8.3 Peripheral Function Initialization

Figure 5.4 is a flowchart of the peripheral function initialization routine.




Figure 5.4 Peripheral Function Initialization

5.8.4 MTU Initialization

Figures 5.5 and 5.6 are a flowchart of the MTU initialization routine.




Figure 5.5 MTU Initialization (1/2)




Figure 5.6 MTU Initialization (2/2)

5.8.5 PWM Output Pin Switching

Figure 5.7 is a flowchart of the PWM output pin switching routine.




Figure 5.7 PWM Output Pin Switching

5.8.6 PWM Output Pin Group 0 Settings

Figure 5.8 is a flowchart of the PWM output pin group 0 settings routine.




Figure 5.8 PWM Output Pin Group 0 Settings

5.8.7 PWM Output Pin Group 1 Settings

Figure 5.9 is a flowchart of the PWM output pin group 1 settings routine.




Figure 5.9 PWM Output Pin Group 1 Settings

5.8.8 Switch Input Determination

Figure 5.10 is a flowchart of the switch input determination routine.




Figure 5.10 Switch Input Determination

5.8.9 MTU3.TGIA3 Interrupt Handler

Figure 5.11 is a flowchart of the MTU3.TGIA3 interrupt handler.




Figure 5.11 MTU3.TGIA3 Interrupt Handler

6. Sample Code

Sample code can be downloaded from the Renesas Electronics website.

7. Reference Documents

User's Manual: Hardware

RX220 Group User's Manual: Hardware Rev.1.00 (R01UH0292EJ)

The latest version can be downloaded from the Renesas Electronics website.

Technical Update/Technical News

The latest information can be downloaded from the Renesas Electronics website.

User's Manual: Development Tools

RX Family C/C++ Compiler Package V.1.01 User's Manual Rev.1.00 (R20UT0570EJ)

The latest version can be downloaded from the Renesas Electronics website.

Website and Support

Renesas Electronics website

http://www.renesas.com

Inquiries

http://www.renesas.com/contact/

| | RX220 Group Application Note Application Example of Exclusive |
|------------------|---|
| REVISION HISTORY | Operation of Two Motors by One Set of Complementary PWM |
| | Outputs |

| Rev. | Date | Description | | |
|------|--------------|-------------|----------------------|--|
| | | Page | Summary | |
| 1.00 | Oct. 1, 2014 | _ | First edition issued | |
| | | | | |

All trademarks and registered trademarks are the property of their respective owners.

General Precautions in the Handling of MPU/MCU Products

The following usage notes are applicable to all MPU/MCU products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.
 In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed. In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.
- 3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

— The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

— When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

The characteristics of an MPU or MCU in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

- 1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein
- 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
- 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics

- You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries. (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



SALES OFFICES

Renesas Electronics Corporation

http://www.renesas.com

Refer to "http://www.renesas.com/" for the latest and detailed information

Renesas Electronics America Inc. 2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A. Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited 1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH Arcadiastrasse 10, 40472 Düsseldorf, Germany Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.
Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.
Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333
Tei: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong Tel: +852-2265-6688, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd. 13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd. 80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949 Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.
Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd. 12F., 234 Teheran-ro, Gangnam-Ku, Seoul, 135-920, Korea Tel: +82-2-558-3737, Fax: +82-2-558-5141

© 2014 Renesas Electronics Corporation. All rights reserved.