

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: “Standard”, “High Quality”, and “Specific”. The recommended applications for each Renesas Electronics product depends on the product’s quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as “Specific” without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as “Specific” or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is “Standard” unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
 - “Standard”: Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
 - “High Quality”: Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.
 - “Specific”: Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) “Renesas Electronics” as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) “Renesas Electronics product(s)” means any product developed or manufactured by or for Renesas Electronics.

M32C/80 Series

Using DMACII (Burst Transfer)

1. Abstract

This application note describes how to use DMACII in burst transfer.

2. Introduction

The explanation of this issue is applied to the following condition:

Applicable MCU: M32C/80 Series

This program can also be used when operating other microcomputers within the M16C family, provided they have DMACII function. However, some functions may have been modified.

Refer to the User's Manual for details. Use functions covered in this Application Note only after careful evaluation.

3. Detailed description

The following explains an example use of DMACII transfer for the case where when an interrupt request which has had its priority level set to 7 by the interrupt control register occurs, data is transferred from one memory location to another by a DMACII transfer a specified number of times successively.

During a burst transfer, the user program is not executed. Nor are interrupts accepted.

3.1 DMAC II Transfer Mode

This application note example offers functions of single transfer mode shown in Table 1.

Table 1. Selectable Functions in Single Transfer Mode

Item	Definition	Selection
Transfer Block	8 bits	Yes
	16 bits	
Transfer Data	Immediate data	
	Data in memory	Yes
Source Direction	Fixed address	
	Forward address	Yes
Destination Direction	Fixed address	Yes
	Forward address	
Calculation Transfer Function	Without Calculation Transfer Function	Yes
	With Calculation Transfer Function	
End-of-Transfer Interrupt	Interrupts not used	Yes
	Interrupts used	
Chained Transfer Function	Not chain transferred	Yes
	Chain transferred	

3.2 DMAC II Index

The DMAC II index is configured with 8 bytes when interrupts and chain transfers are not used in burst transfer mode. The DMAC II index must be located on the RAM area.




Figure 1.DMAC II Index

3.3 DMAC II Transfer

The interrupt requests from all peripheral functions whose ILVL2–ILVL0 bits in the interrupt control register have been set to “111b” constitute the cause of requests to DMAC II. In this application note, the INT0 interrupt is used for the cause of DMAC II request.


3.4 Setting Up the Relocatable Vector Table

Set the beginning address of the DMAC II index in the interrupt vector for the peripheral function interrupt that constitutes the cause of DMAC II request.


3.5 Register Setting

To enable the operation defined in "Section 3. Detailed description", the following register settings must be taken place step by step. For detail configuration of each register, please refer to M32C/80 Series HARDWARE MANUAL.

(1) Transfer mode (MOD)




(2) Transfer count (COUNT)



Set the number of times transferred.


For a burst transfer, once the cause of a DMACII transfer occurs, a DMACII transfer is performed a number of times as set by the transfer count.

(3) Transfer source address (SADR)




Set the source address of transfer.

(4) Transfer destination address (DADR)




Set the destination address of transfer.

(5) RLVL register



(6) Interrupt Control Register



4. Example of a Sample Program

4.1 C language source

```

/*****
/* FILENAME: rej05b0639_src.c
/* Ver : 1.00
/* FUNCTION: DMACII(Burst Transfer)
/*****
/*****/
/* include file */
/*****/
#include <stdio.h>
#include "sfr32c83.h"

/*****/
/* DMACII */
/*****/
struct{
    union {
        struct{
            char size:1; /* Transfer Unit Select Bit */
            char imm:1; /* Transfer Data Select Bit */
            char upds:1; /* Transfer Source Direction Select Bit */
            char updd:1; /* Transfer Destination Direction Select Bit */
            char oper:1; /* Calculation Transfer Function Select Bit */
            char brst:1; /* Burst Transfer Select Bit */
            char inte:1; /* End-of-Transfer Interrupt Select Bit */
            char chain:1; /* Chained Transfer Select Bit */
            char reserve:7;
            char mult:1; /* Multiple Transfer Select Bit */
        }bit;
        unsigned short all;
    }mod;
    unsigned short count; /* Transfer count */
    unsigned char near *sadr; /* Transfer source address */
    unsigned char near *dadr; /* Transfer destination address */
}dm_index;

/* Transfer data array */
static unsigned char near data[5] = {0x11,0x22,0x33,0x44,0x55};

/* Transfer destination */
static unsigned char near dest;

/*****/
/* main */
/*****/
void main(void){
    asm(" fclr i "); /* Interrupt disable */
    /* DMACII setting */
    dm_index.mod.all = 0x0026; /* Transfer Unit: 8bit */
                                /* Transfer Data: Memory */

```

```

/* Transfer Source:      Forward */
/* Transfer Destination:Fixed */
/* Calculation Transfer:None */
/* Burst Transfer:      Burst */
/* Interrupt:           None */
/* Chained Transfer:    None */
/* Multiple Transfer:    None */

dm_index.count = 5;      /* number of transfer = 5 */
dm_index.sadr = data;    /* Source of transfer = beginning address of the data array */
dm_index.dadr = &dest;   /* Destination of transfer = dest */

/* Set the interrupt used for DMAC II */
rlvl = 0x20;            /* Interrupt priority level 7 is used for DMAC II transfers */

int0ic = 0x07;          /* INTO interrupt level 7 (used for DMACII) */

while(1);
}

```

4.2 Relocatable Vector Tables

```

;-----
; variable vector section
;-----
        .section vector,ROMDATA          ; variable vector table
        .org      VECTOR_ADR

        .lword    dummy_int              ; BRK (software int 0)
        .lword    dummy_int              ;
        .lword    dummy_int              ;
        .lword    dummy_int              ;
        .lword    dummy_int              ;
        .lword    dummy_int              ;
        .lword    dummy_int              ;
        .lword    dummy_int              ; DMA0 (software int 8)
;
;
;          (Omission)
;
        .lword    dummy_int              ; INT5 (software int 26)
        .lword    dummy_int              ; INT4 (software int 27)
        .lword    dummy_int              ; INT3 (software int 28)
        .lword    dummy_int              ; INT2 (software int 29)
        .lword    dummy_int              ; INT1 (software int 30)
        .glb      _dm_index
        .lword    _dm_index              ; INTO (software int 31)
        .lword    dummy_int              ; TIMER B5 (software int 32)
;
;
;          (Omission)
;
;

```


5. Reference

Renesas Technology Corporation Home Page

<http://www.renesas.com/>

E-mail Support

E-mail: csc@renesas.com

Hardware Manual

M32C/80 Group Hardware Manual

(Use the latest version on the home page: <http://www.renesas.com>)

TECHNICAL UPDATE/TECHNICAL NEWS

(Use the latest information on the home page: <http://www.renesas.com>)

REVISION HISTORY

Rev.	Date	Description	
		Page	Summary
1.00	2005.05.20	-	First edition issued

Keep safety first in your circuit designs!

1. Renesas Technology Corporation puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage. Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corporation product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corporation or a third party.
2. Renesas Technology Corporation assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corporation without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor for the latest product information before purchasing a product listed herein.
The information described here may contain technical inaccuracies or typographical errors. Renesas Technology Corporation assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.
Please also pay attention to information published by Renesas Technology Corporation by various means, including the Renesas Technology Corporation Semiconductor home page (<http://www.renesas.com>).
4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corporation assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
5. Renesas Technology Corporation semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corporation or an authorized Renesas Technology Corporation product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
6. The prior written approval of Renesas Technology Corporation is necessary to reprint or reproduce in whole or in part these materials.
7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.
Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
8. Please contact Renesas Technology Corporation for further details on these materials or the products contained therein.