To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

   "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

   "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

   "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

SH7000 Series

Quotient of 32 Bit ÷ 32 Bit (Unsigned)

Label: DIVU32Q

Functions Used: DIV0U Instruction
DIV1 Instruction

Contents

1. Function

Divides the dividend (unsigned 32 bits) by the divisor (unsigned 32 bits), and determines the quotient (unsigned 32 bits). Also indicates errors (division by 0) in the T bit.

2. Arguments

Description		Storage Location	Data Length (Bytes)
Input	Dividend (unsigned 32 bits)	R1	4
	Divisor (unsigned 32 bits)	R0	4
Output	Quotient (unsigned 32 bits)	R1	4
	Error (division by 0) generated/not generated (generated: T = 1, not generated: T = 0)	T bit (SR)	4

3. Internal Register Changes and Flag Changes

	(Before Execution) → (After Execution)
R0	Divisor (unsigned 32 bits) → No change
R1	Dividend (unsigned 32 bits) → Quotient (unsigned 32 bits)
R2	Work
R3	
R4	
R5	
R6	
R7	
R8	
R9	
R10	
R11	
R12	
R13	
R14	
R15	(SP)

T bit | * |

— : No change
* : Change
0 : Fixed 0
1 : Fixed 1

4. Programming Specifications

Program memory (bytes)
152
Data memory (bytes)
0
Stack (bytes)
4
Number of states
74
Reentrant
Yes
Relocation
Yes
Intermediate interrupt
Yes

5. Notes

The number of states indicated in the programming specifications is the value when H'FFFFFFFF ÷ H'FFFFFFFE is calculated.

6. Description

(1) Function

Details of the arguments are as follows.

R0: Set the divisor (unsigned 32 bits) as the input argument.

R1: Set the dividend (unsigned 32 bits) as the input argument.
Holds the quotient (unsigned 32 bits) as the output argument.

T bit (SR): Indicates whether an error (division by 0) has occurred.
T bit = 1: Indicates an error (division by 0) has occurred.
T bit = 0: Indicates no error (division by 0) has occurred.

Figure 1 shows a software DIVU32Q execution example.



Figure 1 Software DIVU32Q Execution Example

(2) Usage Notes

After execution of software instruction DIVU32Q, the quotient is set in R1, which previously contained the dividend, and the dividend is destroyed. If the value for the dividend will be needed after the software DIVU32Q instruction is executed, it should be saved beforehand.

(3) RAM Used

No RAM is used by the software DIVU32Q instruction.

(4) Usage Example

After the dividend and divisor are set in the input arguments, the software instruction DIVU32Q is executed by a subroutine call.

```
        MOV.L   DATA1,R1    ....  Sets dividend (unsigned 32 bits) in input argument (R1)
        BSR     DIVU32Q     .... Subroutine call to software instruction DIVU32Q
        MOV.L   DATA2,R0    .... Sets divisor (unsigned 32 bits) in input argument (R0)
        BT      ERROR       .... Branches to error processing subroutine if error (division by 0) occurs
                .
                .
                .
                .
      .align    4
DATA1 .data.l   H'FFFFFFFF
DATA2 .data.l   H'FFFFFFFE
```

(5) Operating Principle

(a) Before division, the following initial settings are carried out.

(i) R2 is used for the upper 32 bits to zero-extend the dividend to 64 bits. (Figure 2-(1))

(ii) The M, Q, and T bits used in one-step division are set to division values. (Figure 2-(2))



Figure 2 Initial Settings

(b) As shown in figure 3, the division operation is repeated through the number of divisor bits (32 times) using the ROCTL and DIV1 instructions.



Figure 3 Division

(c) As shown in figure 4, the 32nd quotient of one-step division is stored in the T bit at the end of division. The 32nd quotient of one-step division stored in the T bit is stored in the LSB of R1, and the R1 contents are the final quotient.



Figure 4 Quotient

7. Flowchart


DIVS32Q
Save registers
Divisor = 0?
Yes
No
Zero-extend dividend to 64 bits
Initialize M, Q, and T bits to unsigned division values
Repeat the following process through the number of divisor bits (32 times)
ROTCL R1
DIV1 R0,R2
Set T bit
Store the 32nd one-step division quotient (T bit) in LSB of R1
Clear T bit
Restore registers
RTS

8. Program Listing

```
 1                          1  ;*************************************************************
 2                          2  ;*                                                           *
 3                          3  ;*      NAME ; QUOTIENT OF 32 BIT UNSIGNED DIVISION (DIVU32Q) *
 4                          4  ;*                                                           *
 5                          5  ;*************************************************************
 6                          6  ;*                                                           *
 7                          7  ;*      ENTRY : R1 (DIVIDEND)                                *
 8                          8  ;*              R0 (DIVISOR)                                 *
 9                          9  ;*    RETURNS : R1 (QUOTIENT)                                *
10                         10  ;*              T BIT (ERROR -> TRUE;T=1,FALSE;T=0           *
11                         11  ;*                                                           *
12                         12  ;*************************************************************
13 00001000                13          .SECTION A,CODE,LOCATE=H'1000
14          00001000       14  DIVU32Q .EQU    $           ; Entry point
15 00001000 2F26           15          MOV.L   R2,@-R15    ; Escape register
16 00001002 2008           16          TST     R0,R0       ; Divisor = 0 ?
17 00001004 8945           17          BT      DIVU32Q1    ; Yes
18 00001006 222A           18          XOR     R2,R2       ; R2 <- H'00000000
19 00001000 0019           19          DIV0U               ; Divide as unsigned
20                         20                              ;
21 0000100A 4124           21          ROTCL   R1          ; Divide 1 step
22 0000100C 3204           22          DIV1    R0,R2       ;
23 0000100E 4124           23          ROTCL   R1          ;
24 00001010 3204           24          DIV1    R0,R2       ;
25 00001012 4124           25          ROTCL   R1          ;
26 00001014 3204           26          DIV1    R0,R2       ;
27 00001016 4124           27          ROTCL   R1          ;
28 00001018 3204           28          DIV1    R0,R2       ;
29 0000101A 4124           29          ROTCL   R1          ;
30 0000101C 3204           30          DIV1    R0,R2       ;
31 0000101B 4124           31          ROTCL   R1          ;
32 00001020 3204           32          DIV1    R0,R2       ;
33 00001022 4124           33          ROTCL   R1          ;
34 00001024 3204           34          DIV1    R0,R2       ;
35 00001026 4124           35          ROTCL   R1          ;
36 00001028 3204           36          DIV1    R0,R2       ;
37                         37                              ;
38 0000102A 4124           38          ROTCL   R1          ;
39 0000102C 3204           39          DIV1    R0,R2       ;
40 0000102E 4124           40          ROTCL   R1          ;
41 00001030 3204           41          DIV1    R0,R2       ;
42 00001032 4124           42          ROTCL   R1          ;
43 00001034 3204           43          DIV1    R0,R2       ;
44 00001036 4124           44          ROTCL   R1          ;
45 00001038 3204           45          DIV1    R0,R2       ;
46 0000103A 4124           46          ROTCL   R1          ;
47 0000103C 3204           47          DIV1    R0,R2       ;
48 0000103E 4124           48          ROTCL   R1          ;
49 00001040 3204           49          DIV1    R0,R2       ;
```

```
 50 00001042 4124          50          ROTCL   R1          ;
 51 00001044 3204          51          DIV1    R0,R2       ;
 52 00001046 4124          52          ROTCL   R1          ;
 53 00001048 3204          53          DIV1    R0,R2       ;
 54                        54                              ;
 55 0000104A 4124          55          ROTCL   R1          ;
 56 0000104C 3204          56          DIV1    R0,R2       ;
 57 0000104E 4124          57          ROTCL   R1          ;
 58 00001050 3204          58          DIV1    R0,R2       ;
 59 00001052 4124          59          ROTCL   R1          ;
 60 00001054 3204          60          DIV1    R0,R2       ;
 61 00001056 4124          61          ROTCL   R1          ;
 62 00001058 3204          62          DIV1    R0,R2       ;
 63 0000105A 4124          63          ROTCL   R1          ;
 64 0000105C 3204          64          DIV1    R0,R2       ;
 65 0000105E 4124          65          ROTCL   R1          ;
 66 00001060 3204          66          DIV1    R0,R2       ;
 67 00001062 4124          67          ROTCL   R1          ;
 68 00001064 3204          68          DIV1    R0,R2       ;
 69 00001066 4124          69          ROTCL   R1          ;
 70 00001068 3204          70          DIV1    R0,R2       ;
 71                        71                              ;
 72 0000106A 4124          72          ROTCL   R1          ;
 73 0000106C 3204          73          DIV1    R0,R2       ;
 74 0000106E 4124          74          ROTCL   R1          ;
 75 00001070 3204          75          DIV1    R0,R2       ;
 76 00001072 4124          76          ROTCL   R1          ;
 77 00001074 3204          77          DIV1    R0,R2       ;
 78 00001076 4124          78          ROTCL   R1          ;
 79 00001078 3204          79          DIV1    R0,R2       ;
 80 0000107A 4124          80          ROTCL   R1          ;
 81 0000107C 3204          81          DIV1    R0,R2       ;
 82 0000107E 4124          82          ROTCL   R1          ;
 83 00001080 3204          83          DIV1    R0,R2       ;
 84 00001082 4124          84          ROTCL   R1          ;
 85 00001084 3204          85          DIV1    R0,R2       ;
 86 00001086 4124          86          ROTCL   R1          ;
 87 00001088 3204          87          DIV1    R0,R2       ;
 88                        88                              ;
 89 0000108A 4124          89          ROTCL   R1          ;
 90 0000108C 0008          90          CLRT                ; T bit <- No error
 91 0000108E 000B          91          RTS                 ;
 92 00001090 62F6          92          MOV.L   @R15+,R2    ; Return register
 93 00001092               93   DIVU32Q1                  ;
 94 00001092 0018          94          SETT                ; T bit <- Error
 95 00001094 000B          95          RTS                 ;
 96 00001096 62F6          96          MOV.L   @R15+,R2    ; Return register
 97                        97          .END
*****TOTAL ERRORS    0
*****TOTAL WARNINGS  0
```

Keep safety first in your circuit designs!

1. Renesas Technology Corp. puts the maximum effort into making semiconductor products better and more reliable, but there is always the possibility that trouble may occur with them. Trouble with semiconductors may lead to personal injury, fire or property damage.
   Remember to give due consideration to safety when making your circuit designs, with appropriate measures such as (i) placement of substitutive, auxiliary circuits, (ii) use of nonflammable material or (iii) prevention against any malfunction or mishap.

Notes regarding these materials

1. These materials are intended as a reference to assist our customers in the selection of the Renesas Technology Corp. product best suited to the customer's application; they do not convey any license under any intellectual property rights, or any other rights, belonging to Renesas Technology Corp. or a third party.
2. Renesas Technology Corp. assumes no responsibility for any damage, or infringement of any third-party's rights, originating in the use of any product data, diagrams, charts, programs, algorithms, or circuit application examples contained in these materials.
3. All information contained in these materials, including product data, diagrams, charts, programs and algorithms represents information on products at the time of publication of these materials, and are subject to change by Renesas Technology Corp. without notice due to product improvements or other reasons. It is therefore recommended that customers contact Renesas Technology Corp. or an authorized Renesas Technology Corp. product distributor for the latest product information before purchasing a product listed herein.
   The information described here may contain technical inaccuracies or typographical errors.
   Renesas Technology Corp. assumes no responsibility for any damage, liability, or other loss rising from these inaccuracies or errors.
   Please also pay attention to information published by Renesas Technology Corp. by various means, including the Renesas Technology Corp. Semiconductor home page (http://www.renesas.com).
4. When using any or all of the information contained in these materials, including product data, diagrams, charts, programs, and algorithms, please be sure to evaluate all information as a total system before making a final decision on the applicability of the information and products. Renesas Technology Corp. assumes no responsibility for any damage, liability or other loss resulting from the information contained herein.
5. Renesas Technology Corp. semiconductors are not designed or manufactured for use in a device or system that is used under circumstances in which human life is potentially at stake. Please contact Renesas Technology Corp. or an authorized Renesas Technology Corp. product distributor when considering the use of a product contained herein for any specific purposes, such as apparatus or systems for transportation, vehicular, medical, aerospace, nuclear, or undersea repeater use.
6. The prior written approval of Renesas Technology Corp. is necessary to reprint or reproduce in whole or in part these materials.
7. If these products or technologies are subject to the Japanese export control restrictions, they must be exported under a license from the Japanese government and cannot be imported into a country other than the approved destination.
   Any diversion or reexport contrary to the export control laws and regulations of Japan and/or the country of destination is prohibited.
8. Please contact Renesas Technology Corp. for further details on these materials or the products contained therein.